

# SAFETY RECALL

## Winchester® Hunting Knife Set (Model # 31-000801)

In some Knife Sets, the handle's latching mechanism does not work correctly in all situations; therefore, some blades can be pulled out of the handle without the user pushing the lock release button. This potentially could result in a blade falling out of or disengaging from the handle during use. This issue may pose a laceration hazard to the user.



If you have a Winchester® Hunting Knife Set, stop using it immediately and contact Gerber to receive instructions on how to return the Hunting Knife Set for a free replacement product of equal or higher value. Gerber will provide you with instructions on how to return the product, along with a prepaid shipping container.

Call Gerber between 9 a.m. and 5 p.m. PT, Monday through Friday, at:

**(877) 314-9130**

or visit Gerber's website: [www.gerbergear.com](http://www.gerbergear.com)